



ITEM #: M6RTS02 RECEIVER

PROGRAMMING PROCEDURE

- Each M6RTS Receiver can memorize up to 12 Transmitters.
- Mount the M6RTS Receiver with the antenna pointing up for best reception.

1. Connect the RTS Receiver to the M6 Motor "S" or "M" Class on EYE1 Port. The LED will be lit until a transmitter is programmed into memory.

2. INITIAL PROGRAMMING: To program the first transmitter or channel, press and hold the program button on the back of a Telis transmitter until the LED on the receiver turns off. Release the program button on the LED will light again. Press and release the program button on the same transmitter again and the LED will turn off and remain off. This transmitter is now memorized.

3. PROGRAMMING ADDITIONAL TRANSMITTERS: Press and hold the programming button of a Telis transmitter that is already memorized by the M6RTS Receiver until the LED on the receiver turns on. Press and release the programming button on the new transmitter or channel. The LED on the receiver will turn off, indicating this transmitter has been memorized. Repeat this procedure for each transmitter or channel, up to 12 total.

4. DELETING A TRANSMITTER FROM MEMORY: Press and hold the programming button of a Telis transmitter already memorized by the M6RTS receiver, but not the one to be removed from memory. Continue holding the button until the LED on the receiver turns on. Press and release the programming button on the transmitter or channel to be removed from memory. The LED on the receiver will turn off, that transmitter will no longer operate the M6RTS Receiver.

5. MEMORY RESET: Press and release the reset button on the M6RTS Receiver. The LED will turn on, indicating that no transmitters or channels are memorized.

6. OPERATION: Pressing the UP button on the Telis Transmitter will raise or retract the window treatment. Pressing the DOWN button will lower or extend it. Pressing the CENTER button will STOP the window treatment.

Questions?

Email us at info@angbejar.com or Call 678.721.1985